
SIWADCP-V6 Preconfigured Signum Complete Scale







SPECIFICATIONS:

Weighing Capacity	65 kg	Platform Size (WxD)	13.7" x 9.4"
Readability	1.0 g	Dimensions (WxD)	13.7" x 16.5"
Linearity	≤± 3 g.	Displ. Dim. (WxHxD)	9.5" x 2.5" x 7"
Reproducibility	≤± 2 g	Display Cable Length	6 feet
Response Time	< 1 seconds	Net Weight	26 1lb.
Operating Temp.	10°C to +40°C	Type of Display	Backlit 14-segment
Protection Rating	IP 65	Overload Capacity	300 kg.
FEATURES: ——			

- The new Signum from Sartorius is a compact industrial scale that offers exceptional performance features and is very easy to operate. Flexible and ergonomic thanks to adaptable mounting options of the control unit in a slim-line design.
- <u>Application Level 3</u> 17 keys, 14 segment display, Applications include Counting, Weighing in Percent, Animal Weighing, Checkweighing,Classification, Totalizing, Net-Total Formulation; 100 product memories, 4 configurable ID fields, combine 3 applications.
- **IP65 Protection Rating** The IP 65 protection rating means the scale is dust-tight and with low-pressure water jet protection. This feature makes these scales suitable for use in some of the harshest industrial environments.
- Optional Additional Interfaces
 Ethernet TCP/IP
 RS232/422/485
 Profibus-DP
 Analog: 4-20mA, 0-20mA, 0-10V 16 Bit
 Digital I/O: 5 in-5 out Opto 130

Sartorius Corporation 131 Heartland Boulevard Edgewood New York 11717 Toll Free: (800) 635-2906 ☎ (631) 254-4249, Fax (631) 254-4252

RS232 Data Interface

The SIWADCP-V6 scales come with a bidirectional interface, which allows for simple connection to a printer or computer for easy data acquisition and automation capabilities. 25-pin D-sub female connector

